



How to Use Vinyl-Off



Vinyl-Off™ is a safe ready to use product designed to speed the removal of vinyl graphics AND adhesive from multiple substrates (metal, glass, canvas, FRP, painted surfaces, gel coat, fiberglass, etc) in one step. Vinyl-Off™ is reduces the time needed to remove failed and difficult to remove vinyl wraps and decals.

Steps

1. **TEST:** Always test Vinyl-Off on an inconspicuous area and ensure the paint is in good condition. Only use Vinyl-Off on properly catalyzed automotive paint without rust or chips.
 2. **WIPE/ROLL:** Use a cloth rag or roller to wipe a thin layer of Vinyl-Off Directly onto the vinyl you intend to remove. On large areas, work in smaller sections.
 3. **WAIT:** Allow a few minutes for the product to dwell on the vinyl. Longer dwell time may be necessary when ambient temperatures are below 60 degrees Fahrenheit.
 4. **HEAT:** Apply a heat source to warm the area and then apply one additional coat of Vinyl-Off. There are no toxic fumes, and this can be done indoors.
 5. **LIFT:** Lift the vinyl at an edge utilizing a non-scratch removal tool. The vinyl will come off in much larger, more flexible pieces.
- IF ADHESIVE IS REMAINING AFTER REMOVAL YOU ARE APPLYING TOO MUCH HEAT. USE LESS HEAT OR SHORTEN DWELL TIME.
 - IF VINYL-OFF IS NOT LIFTING AS YOU WOULD HAVE HOPED, INCREASE HEAT OR DWELL TIME. YOU CAN ROUGH THE VINYL WITH A FINE GRIT SANDPAPER TO INCREASE PENETRATION OF THE VINYL.
 - REMOVE REMAINING ADHESIVE WITH VINYL-OFF OR BROTHERS CHEMICAL ADHESIVE REMOVER.